



Manuel Cabs
www.chillamps.com

Connexions :

Chaque enceinte Chillbass est équipée de deux combos SPEAKON/JACK.
Le branchement du Jack se trouve au milieu de chaque speakon.
Les deux connexions sont reliées entre elles en parallèle.
Vous pouvez choisir l'une ou l'autre.
L'autre sert pour brancher une enceinte en extension.

Impédance et puissance :

L'impédance de l'enceinte est indiquée sur la plaque connectique arrière.
L'utilisateur est censé connaître les règles de calcul d'impédance et la répartition de la puissance qui en découle.

Protection des haut-parleurs:

La puissance maximum autorisée est indiquée sur la plaque connectique arrière. Ne pas alimenter l'enceinte avec une puissance supérieure.

Connections:

Each Chillbass speaker is equipped with two SPEAKON / JACK combos.
Jack hookup is in the middle of each speakon.
The two connections are connected together in parallel.
You can choose one or the other.
The other is used to connect an enclosure in extension.

Impedance and power:

The impedance of the speaker is indicated on the rear connector plate.
The user is supposed to know the rules of impedance calculation and the distribution of the resulting power.

Speaker protection:

The maximum power allowed is indicated on the rear connector plate. Do not power the speaker with higher power.